










abc classic








Agger Deluxe




Agger Deluxe


13  x20	8  x28	87  x12	57  3,5x 12 x8	40  x8	43  x8	44  x8
62  x4	71  x12	89  x4	93  x4	55  x3		
2  x2	60  x2	14  x2	17  x2	 x2		
 x3	 x2	 x2		 x10		 x2
	 x2	 x2		 x1		 x2
 x1						

Agger Deluxe




Agger Deluxe



2  x2	60  x2	14  x4	17  x2
---	--	--	--




5





6





Agger Deluxe




7



A





C



B

8




Dansk: Ved Agger Deluxe & Astrup skal krydset være i sektionen med skrivebordspladen, for øget stabilitet. Ikke bagved skufferne

English: For Agger Deluxe & Astrup, the metal cross must be located in the section with the desktop to enhance stability, not behind the drawers.




German: Bei Agger Deluxe & Astrup muss das Kreuz immer im Bereich mit der Schreibtischplatte angebracht werden, um die Stabilität zu erhöhen, nicht hinter den Schubladen.

abc classic


Agger Deluxe




9




Agger Deluxe




11




Agger Deluxe

40	43	44	62	71	89	93
						
x8	x8	x8	x4	x12	x2	x2

12




13





Agger Deluxe

13	40	43	44	57	62	71	87	89	93
				 3,5x 12					
x8	x4	x4	x4	x4	x2	x6	x6	x2	x2

9 - 13



Agger Deluxe



English

WARNING!

Serious or fatal injuries can occur from furniture tip-over. Use provided wall attachment device(s) to mount the furniture to the wall and to prevent tipping.

Wall screw(s) and plug(s) not included; use suitable ones for your walls. If unsure, seek professional advice. Follow instructions carefully.

Dansk

ADVARSEL!

Fare for alvorlige eller fatale skader, hvis møblet vælter. Brug medfølgende vægbeslag for at fastgøre møblet til væggen og undgå at møblet vælter.



Skrue(r) og rawlplug(s) til væggen medfølger ikke; brug egnede til dine vægge. Hvis du er i tvivl, søg professionel rådgivning. Følg instruktionerne omhyggeligt.

Deutsch

ACHTUNG!

Wenn Möbelstücke umkippen, können ernste oder lebensgefährliche Verletzungen die Folge sein. Verwenden Sie die mitgelieferten Wandbefestigungsvorrichtungen, um das Möbel fest an der Wand zu verankern und ein Umkippen zu verhindern.

Schrauben und Dübel für die Wand sind nicht enthalten; verwenden Sie geeignete für Ihre Wände. Wenn Sie unsicher sind, suchen Sie professionellen Rat. Befolgen Sie die Anweisungen sorgfältig.



55

