




























abc classic







Vangså



Vangså







 13 x20	 8 x28	 87 x12	 57 3,5x12 x8	 40 x8	 43 x8	 44 x8
 62 x4	 71 x12	 89 x4	 93 x4	 55 x3		
 2 x2	 60 x2	 14 x2	 17 x2	 x2		
 x2	 x2	 x2	 x7	 x2		
	 x2	 x2	 x1	 x2		

Vangså



abc classic



Vangså





3

abc classic



Vangså










5




Vangså




Vangså

40	43	44	62	71	89	93
						
x8	x8	x8	x4	x12	x2	x2











8





9




Vangså

 x8	 x4	 x4	 x4	 3,5x12 x4	 x2	 x6	 x6	 x2	 x2
---	---	---	---	---	---	--	---	---	---


 5 - 9



10



Vangså



English

WARNING!

Serious or fatal injuries can occur from furniture tip-over. Use provided wall attachment device(s) to mount the furniture to the wall and to prevent tipping.

Wall screw(s) and plug(s) not included; use suitable ones for your walls. If unsure, seek professional advice. Follow instructions carefully.

Dansk

ADVARSEL!

Fare for alvorlige eller fatale skader, hvis møblet vælter. Brug medfølgende vægbeslag for at fastgøre møblet til væggen og undgå at møblet vælter.

Skrue(r) og rawlplug(s) til væggen medfølger ikke; brug egnede til dine vægge. Hvis du er i tvivl, søg professionel rådgivning. Følg instruktionerne omhyggeligt.

Deutsch

ACHTUNG!

Wenn Möbelstücke umkippen, können ernste oder lebensgefährliche Verletzungen die Folge sein. Verwenden Sie die mitgelieferten Wandbefestigungsvorrichtungen, um das Möbel fest an der Wand zu verankern und ein Umkippen zu verhindern.

Schrauben und Dübel für die Wand sind nicht enthalten; verwenden Sie geeignete für Ihre Wände. Wenn Sie unsicher sind, suchen Sie professionellen Rat. Befolgen Sie die Anweisungen sorgfältig.

